



# Quick Start Guide



1. Assure you install the software included with your ProLaunch monitor. Previously versions of the software may not recognize your ProLaunch unit.
2. Plug the Power Supply into the ProLaunch unit and a functional surge suppressor (recommended) or wall outlet.
3. Plug the USB Cable into the ProLaunch unit and any USB Port (USB 2.0 or above) on your PC.
4. Plug the trigger cable into the ProLaunch unit.
5. Affix the trigger cable into the exit row slot of the sensor unit. This needs to be fully pressed to the outer edge of the slot.



The software should automatically detect the ProLaunch Unit. If you find you are not getting the video window, you can go to Options->Video Camera Settings to verify the ProLaunch is being used.

