

## QUICK START GUIDE

**1 Install the software.** Insert the CD into the CD/DVD drive on your computer. The installation program should begin automatically.

**2 Connect the hardware.**


1. Connect the power supply to the sensor unit and plug into a surge protector.
2. Connect the USB cable to the sensor unit.
3. Plug the USB cable into a USB port on your computer.
4. If you ordered additional course packs: Plug the SmartDongle security key USB into a USB port on your computer. Installation of courses will begin automatically.

*NOTE: You will only have a SmartDongle if you ordered additional courses.*


**3** Once all hardware is connected, launch the P3ProSwing Golf Software using the desktop icon.

**4 Tape your clubs.** Instructions are available for driver/hybrid clubs, irons and putters in the User Guide located on the desktop.

*NOTE: Most chrome-plated (shiny silver) irons will not require club tape in order to register swings.)*



### TAPING INSTRUCTIONS - DRIVER/HYBRID USED



Loosely stick the edge of the tape on the applicator guide. Align the reflective strip with the ridges on the guide. Line up the applicator guide parallel to the club face and centered on the sweet spot.



Once aligned, firmly press tape onto the bottom of the club and around the edges. Be sure to smooth out the tape.



The tape should be placed so that a small portion is on the face of the club as shown above.



This image shows the reflective strip centered on the sweet spot.



Many clubs have the club number displayed on the bottom of the club which the tape may cover. Apply a club number provided in your goodie bag to the hosel for easy club selection.

**5 View the User Guide.** The User Guide is located on the desktop and has details on product use, features of P3ProSwing and troubleshooting.